


# 266-EN



## WIRELESS CONTROLLER & BRIDGE INSTALLATION & INTERFACE GUIDE GEN 2



**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

**Guide No. 266-EN**

WIRELESS CONTROLLER & BRIDGE  
INSTALLATION & INTERFACE GUIDE

Date: MAR / 2023



# Contents

|  |           |
|--|-----------|
| <b>1.0 SAFETY WARNING</b>                                    | <b>1</b>  |
| <b>2.0 LANDING DOOR CONTROLLER INSTALLATION</b>              | <b>2</b>  |
| 2.1 LANDING DOOR CONTROLLER MOUNTING                         | 2         |
| 2.2 LANDING DOOR WIRING LAYOUT - STANDARD OPERATORS (OPTION) | 3         |
| 2.3 LANDING DOOR WIRING LAYOUT - EXTRA HIGH TORQUE OPERATORS | 4         |
| 2.4 LANDING DOOR POWER CONNECTIONS                           | 5         |
| 2.5 LANDING DOOR ENCODER                                     | 6         |
| 2.6 LANDING DOOR OPERATORS - STANDARD OPERATORS              | 7         |
| 2.7 LANDING DOOR OPERATORS - EXTRA HIGH TORQUE (OPTION)      | 8         |
| 2.8 LANDING DOOR EMERGENCY UNLOCKING DEVICE (EUD)            | 9         |
| 2.9 LANDING DOOR ZONE SWITCH (ZNS)                           | 10        |
| 2.10 LANDING DOOR HALL PUSHBUTTONS                           | 11        |
| 2.11 LANDING DOOR LIGHT CURTAIN (OPTIONAL)                   | 12        |
| <b>3.0 CAR DOOR (GATE) CONTROLLER INSTALLATION</b>           | <b>13</b> |
| 3.1 CAR DOOR LOCATION AND WIRING LAYOUT                      | 13        |
| 3.2 CAR DOOR POWER CONNECTIONS                               | 14        |
| 3.3 CAR DOOR ENCODER   | 15        |
| 3.4 CAR DOOR (GATE) OPERATOR                                 | 16        |
| 3.5 RETIRING CAM MOTOR                                       | 17        |
| 3.6 CAR DOOR REVERSING EDGE (OPTIONAL)                       | 18        |
| 3.7 SINGLE LIGHT CURTAIN (OPTION)                            | 19        |
| 3.8 DUAL LIGHT CURTAINS (OPTION)                             | 20        |
| 3.9 WARNING BUZZER   | 21        |
| 3.10 CAR STATION DOOR PUSHBUTTONS                            | 22        |
| <b>4.0 BRIDGE CONTROLLER INSTALLATION</b>                    | <b>23</b> |
| 4.1 BRIDGE CONTROLLER LOCATION AND WIRING LAYOUT             | 23        |
| 4.2 BRIDGE POWER CONNECTIONS                                 | 24        |
| 4.3 BRIDGE TO CAR DOOR CONNECTION                            | 25        |
| 4.4 ELEVATOR TO BRIDGE CONTROLLER INPUT CONNECTIONS          | 26        |
| 4.5 BRIDGE CONTROLLER TO ELEVATOR OUTPUT CONNECTIONS         | 28        |



## THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES

TECHNICAL SUPPORT 1-800-787-5020 ext 275

## Guide No. 266-EN

WIRELESS CONTROLLER & BRIDGE  
INSTALLATION & INTERFACE GUIDE

Date: MAR / 2023

|            |  |           |
|------------|--|-----------|
| <b>5.0</b> | <b>COMMISSIONING</b>                                 | <b>29</b> |
| 5.1        | CAR DOOR COMMISSIONING                               | 29        |
| 5.2        | LANDING DOOR COMMISSIONING                           | 31        |
| 5.3        | OPERATION AND TESTING - FROM THE CAR DOOR CONTROLLER | 32        |
| 5.4        | SEQUENCE OF OPERATION                                | 32        |
| 5.5        | POWER UP MODE / LOSS OF POWER                        | 32        |
| 5.6        | BRIDGE COMMISSIONING                                 | 33        |
| 5.7        | LANDING AND CAR DOOR INTERLOCKING CIRCUITS           | 34        |
| <b>6.0</b> | <b>CONTROLLER SETTINGS</b>                           | <b>35</b> |
| 6.1        | DOOR MOTION PROFILES                                 | 35        |
| 6.2        | CAR & LANDING DOOR CONTROLLER PARAMETERS             | 35        |
| 6.3        | BRIDGE CONTROLLER PARAMETERS                         | 38        |
| <b>7.0</b> | <b>TROUBLESHOOTING</b>                               | <b>39</b> |
| 7.1        | INDEPENDENT MODE                                     | 39        |
| 7.2        | AUTOMATIC MODE                                       | 40        |
| 7.3        | ELEVATOR INTERFACE OPERATION                         | 41        |
| 7.4        | ERROR CODES  | 42        |
| 7.5        | LANDING DOOR LCD                                     | 43        |
| 7.6        | CAR DOOR LCD   | 44        |
| 7.7        | BRIDGE LCD   | 45        |
| <b>8.0</b> | <b>TECHNICAL SPECIFICATIONS</b>                      | <b>46</b> |
| <b>9.0</b> | <b>EC DECLARATION OF CONFORMITY</b>                  | <b>47</b> |



**THE PEELLE COMPANY**

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES

**TECHNICAL SUPPORT** 1-800-787-5020 ext 275

**Guide No. 266-EN**

WIRELESS CONTROLLER & BRIDGE  
INSTALLATION & INTERFACE GUIDE

Date: MAR / 2023

## 1.0 SAFETY WARNING



**Electrical Hazard Warning Symbol** – Failure to observe this warning could result in electrical shock or electrocution.



**Operational Hazard Warning Symbol** – Failure to observe this warning could result in dangerous or unsafe conditions.

**Installation Note:** This product should be installed and serviced by a qualified elevator technician familiar with its operation and hazards involved. Proper safety procedures must be followed when working with this controller during installation and with control under power. Proper shielding and grounding of this product is necessary to reduce the emissions of radio frequency interference (RFI) which may adversely affect sensitive electronic equipment.

**Electrical Wiring:** Wire controller in accordance with the National Electrical Code, Canadian Electrical Code, European Norms and/or any other local codes that apply.

**General Contractor Note:** A separate fuse disconnect switch is required for the door controllers. See job specific wiring diagrams for disconnect and fuse requirements.

### Enclosure Conduit Connections

TYPE 1, 4 & 4X  
(Indoor Use Only)

#### CAUTION


Non-metallic enclosure does not provide grounding between conduit connections. Use grounding bushing and jumping wires.

#### WARNING

Do not mount controller on or above a combustible surface.

The conduit hubs are to be connected to the conduit before being connected to the enclosure.

To maintain the environmental rating of this enclosure, install in any openings only listed or recognized conduit hubs with the same environmental ratings as required, in compliance with the installation instructions of the device.



**THE PEELLE COMPANY**

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES

TECHNICAL SUPPORT 1-800-787-5020 ext 275

1

**Guide No. 266-EN**


WIRELESS CONTROLLER & BRIDGE  
INSTALLATION & INTERFACE GUIDE

Date: MAR / 2023

## 2.0 LANDING DOOR CONTROLLER INSTALLATION

### 2.1 LANDING DOOR CONTROLLER MOUNTING

Mount the Landing door Controller to the hoistway wall.  
Use 1/4" inch hardware.



**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275


2

**Guide No. 266-EN**

WIRELESS CONTROLLER & BRIDGE  
INSTALLATION & INTERFACE GUIDE

Date: MAR / 2023

## 2.2 LANDING DOOR WIRING LAYOUT - STANDARD OPERATORS (OPTION)




**THE PEELLE COMPANY**  
 FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
 TECHNICAL SUPPORT 1-800-787-5020 ext 275

## 2.3 LANDING DOOR POWER CONNECTIONS

Connect controllers in accordance with local electrical codes. Power branch circuit should come from machine room disconnect 10 amp circuit for each line of doors. Use #14AWG [2mm] copper wire for power connection.

- ON/OFF switch disconnects both lines
- If neutral is not used, main disconnect must break both lines.




**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275



## 2.4 LANDING DOOR ENCODER

Install and wire encoder same side as the controller. Do not extend the encoder wire.




**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

## 2.5 LANDING DOOR OPERATORS - STANDARD OPERATORS

Wire both door motors in parallel. Use #18AWG [1mm] wire in conduit for motor connection. Do not combine motor wires with control wires in same conduit.

Note: Low speed winding is not used. Cap black wires separately (R4-R5).




**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

## 2.6 LANDING DOOR EMERGENCY UNLOCKING DEVICE (EUD)


The Emergency Unlocking Device is located on the landing side and contains a toggle switch which must be wired to the controller.

NOTE: Only in jurisdictions not requiring unlocking devices, a jumper needs to be added in lieu of the EUD switch.




## 2.7 LANDING DOOR ZONE SWITCH (ZNS)

The landing door Zone Switch located in top of interlock box activates the controller for the Landing door at which the elevator car is located.



**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

## 2.8 LANDING DOOR HALL PUSHBUTTONS



### HALL DOOR OPEN BUTTON (HDO) **1**



Where provided, wire landing station door OPEN pushbuttons as shown. When elevator car is within landing ZONE, pushbutton inputs will be transmitted to the Car Door controller for connection to elevator control.

### HALL DOOR CLOSE BUTTON (HDC) **2**

Where provided, wire landing station door CLOSE pushbutton as shown. When elevator car is within floor ZONE, pushbutton inputs will be transmitted to the Car Door controller for connection to elevator control.

### DOOR STOP BUTTON (STOP) **5**

Where provided, wire landing station door STOP pushbutton as shown. The door STOP button should be normally open (NO). If normally closed (NC) set parameter 96 to 01. See DOOR STOP output for connection to elevator control.



The input indicators **1**, **2** and **5** will go ON when the pushbutton is activated for the door connected to that controller.




**THE PEELLE COMPANY**  
 FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
 TECHNICAL SUPPORT 1-800-787-5020 ext 275

## 2.9 LANDING DOOR LIGHT CURTAIN (OPTIONAL)

Install and wire Landing Door Light Curtain where provided.

Note: V+ to RE contact must close when beams are blocked




**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

### 3.0 CAR DOOR (GATE) CONTROLLER INSTALLATION

#### 3.1 CAR DOOR LOCATION AND WIRING LAYOUT

Mount the Car Door Controller to the car door rail spreader. Mount to same side as the Encoder. Use 1/4" Hardware.




**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

### 3.2 CAR DOOR POWER CONNECTIONS

Connect controllers in accordance with local electrical codes. Power branch circuit should come from machine room disconnect 10 amp circuit for each line of doors. Use #14AWG [2mm] copper wire for power connection.


- ON/OFF switch disconnects both lines
- If neutral is not used, main disconnect must break both lines.





### 3.3 CAR DOOR ENCODER

Install and wire encoder. Do not extend the encoder wire.




**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

### 3.4 CAR DOOR (GATE) OPERATOR

Use #18AWG [1mm] wire in conduit for motor connection.  
Do not combine motor wires with control wires in same conduit.  
Note: Low speed winding is not used. Cap black wires separately (T8-T9).

On large car doors  
where provided wire  
opposite car door  
operator in parallel.



**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275


### 3.5 RETIRING CAM MOTOR

Use #18AWG [1mm] wire in conduit for motor connection.  
Do not combine motor wires with control wires in same conduit.

#### Attention!

220 Volt 3 Ø Retiring Cam Motors Only

For 110 Volt 1 Ø Retiring Cam Motors for battery lowering see elevator control panel




**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

### 3.6 CAR DOOR REVERSING EDGE (OPTIONAL)

Wire reversing edge as shown where provided.


 Note V+ to RE contact closes when reversing edge is obstructed.



**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

### 3.7 SINGLE LIGHT CURTAIN (OPTION)


 For Single Light Curtain option, you must add a jumper from V+ to DCM



LIGHT CURTAIN #1 (SE) **3**  
 Wire light curtain RD1 output as shown use normally open (NO) signal from light curtain controller.  
 Wire V+ to Input 4.




### 3.8 DUAL LIGHT CURTAINS (OPTION)




### 3.9 WARNING BUZZER

Install and wire door close warning buzzer as shown. See parameter 94 for constant or pulsing tone.



**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275

### 3.10 CAR STATION DOOR PUSHBUTTONS



#### CAR DOOR OPEN BUTTON (DO) **1**



Wire car station door OPEN pushbutton as shown.

#### CAR DOOR CLOSE BUTTON (DC) **2**

Wire car station door CLOSE pushbutton as shown.

#### CAR DOOR STOP BUTTON (RC) **5**

Where provided, wire car station door STOP pushbutton as shown. The car door STOP button should be normally open (NO). If normally closed (NC) set parameter 96 to 01. See DOOR STOP output on bridge controller for connection to elevator control.



The input indicators **1**, **2** or **5** will go ON when the pushbutton is activated.






## 4.0 BRIDGE CONTROLLER INSTALLATION

### 4.1 BRIDGE CONTROLLER LOCATION AND WIRING LAYOUT


#### MACHINE ROOM



## 4.2 BRIDGE POWER CONNECTIONS

Connect controllers in accordance with local electrical codes. Power branch circuit should come from machine room disconnect 10 amp circuit for each line of doors. Use #14AWG [2mm] copper wire for power connection.

- ON/OFF switch disconnects both lines
- If neutral is not used, main disconnect must break both lines.




### 4.3 BRIDGE TO CAR DOOR CONNECTION

#### CAN BUS WIRING

Wire Bridge Controller to the Car Door Controller in series as shown. Use (2) shielded twisted pair in travel cable.

#### TERMINATING JUMPERS

For elevators with front doors only, do NOT remove terminating jumper. For front & rear doors remove terminating jumper on Front Car Door Controller only.




## 4.4 ELEVATOR TO BRIDGE CONTROLLER INPUT CONNECTIONS


### CONTROLLER INTERFACE

Inputs to the Bridge controller are the only interface to the elevator control for door operation. A single Bridge Controller is used for front doors or for front and rear door arrangement.

### INPUT COM

Add jumper to the INPUT COM from V- when car door controller V+ is used for the input voltage.

 Where elevator control voltage is used, connect **INPUT COM** to elevator controller according to elevator control prints. Do not use V+ or V-.



**THE PEELLE COMPANY**  
 FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
 TECHNICAL SUPPORT 1-800-787-5020 ext 275

## ELEVATOR TO BRIDGE CONTROLLER INPUT CONNECTIONS CONTINUED

- 1 DO - Front Door Open**  
Momentary front signal required to open doors
  - 2 DC - Front Door Close**  
Constant signal required to close doors
  - 3 SE - Front Inspection**  
Constant signal required for front door operation
  - 4 DCM - Front Door Close Momentary**  
Momentary signal required to initiate Auto Close sequence
  - 5 RC - Retiring Cam**  
Input required to lift cam and move car. Signal should be low whenever car is stopped.
  - 6 X11 - Fire Service Phase 1 Recall**  
Input required when Fire Service Phase 1 Recall is on.
  - 7 X12 - Designated Landing Door**  
Input required when elevator is at designated landing
- 
- 1 DOR - Rear Door Open**  
Momentary signal to open doors
  - 2 DCR - Rear Door Close**  
Constant Signal required to close doors
  - 3 INSR - Rear Inspection**  
Constant signal required for rear door operation
  - 4 DCMR - Rear Door Close Momentary**  
Momentary signal required to initiate Auto Close sequence
  - 5 X13 - Phase 2 “ON”**  
Constant signal required in phase 2 operation
  - 6 X14 - Phase 2 “HOLD”**  
Constant signal required in phase 2 “HOLD” operation
  - 7 X18 - Phase 2 “OFF”**  
Constant signal required in phase 2 “OFF” operation (until recall)
  - 8 HDB - Hall Door Button Disable**  
Constant signal required to enable hall buttons



## 4.5 BRIDGE CONTROLLER TO ELEVATOR OUTPUT CONNECTIONS

### Hall Stop Buttons

#### DSF - Front Door Stop - Relay COM1

Contact closes when door stops during operation sequence

#### DSR - Rear Door Stop - Relay COM1

Contact closes when door stops during operation sequence

### Front Door Open - Relay COM2

Normally open contact closes and normally closed contact opens, when landing and car doors are closed

### Front Door Closed

#### Relay COM3

Normally open contact closes and normally closed contact opens, when landing and car doors are closed

### Rear Door Open

#### Relay COM4

Normally open contact closes and normally closed contact opens when landing door and car door are open.

### Rear Door Closed

#### Relay COM5

Normally open contact closes and normally closed contact opens when landing door and car door are closed

### USER 1 - Relay COM6

Default: Normally open contact closes and normally closed contact opens when both landing door and car door are 3/4 open.

Option: see parameter 65

### USER 2 - Relay COM7

Normally open contact closes and normally closed contact opens when both landing door and car door are 3/4 closed.


Option: see parameter 85

### Attention!

See Parameter 97 for power-up mode relay condition.



Elevator controller interface connections to the Bridge Controller ONLY. No connection to landing door controller, or car door controller.



## 5.0 COMMISSIONING


### 5.1 CAR DOOR COMMISSIONING

Make sure all Landing Doors and Car Doors are adjusted and run freely by hand in the door guides without binding or sticking.

### 5.2 INSTALL BATTERIES

Install NIMH batteries in all Landing door and Car door Controllers.


 Batteries not required for Bridge controller



Remove Battery Protection Plate



Install supplied NiMH batteries (only use NiMH)



Replace Battery Protection Plate



**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
TECHNICAL SUPPORT 1-800-787-5020 ext 275


27

**Guide No. 266-EN**

WIRELESS CONTROLLER & BRIDGE  
INSTALLATION & INTERFACE GUIDE


Date: MAR / 2023

### 5.3 CAR DOOR COMMISSIONING STEPS




8. Set parameter 50 to “01” for CAN\_Bridge Operation


2. Set AUTO<>IND switch to IND




3. Using the OPEN, CLOSE and RETCAM cam buttons, ensure the car door operator(s) and retiring cam motor(s) are phased for correct rotation. If a motor rotates in the wrong direction, switch any two of the three motor wires



4. To begin, cycle through parameters by pressing the - & + buttons. Once the desired parameter is displayed, press the ENTER button to access the setting for that parameter. Change the setting by pressing the - & + buttons. Once the desired setting is displayed, press the ENTER button to save the setting. Parameters can only be modified in IND mode.




5. Change parameter 02 to “Cd” setting.  
The LCD display should now read “CAR DOOR”.



6. Use parameter 03 default “CHANNEL 15” for the first car door . For each additional car door , change parameter 03 to a different channel. The LCD display will show what channel has been selected.

If car door stalls before learn is complete, set parameter 12 to HD. Re-run the learn cycle. Adjust speeds to suit to ensure car door does not slam.


**Quick Tip**



7. Change parameter 10 to “Lr” setting. Press ENTER to begin learn cycle. Prior to learn, car door can be in any position. The learn cycle will fully close and then fully open. Once the car door is fully open, the learn cycle is complete and the flashing “LEARN” indicator on the LCD will turn off.

If car door stalls during operation (normal operation or nudging), set parameter 12 to HD. Adjust speeds to suit to ensure car door does not slam.

**Quick Tip**



8. Set parameter 50 to “01” for CAN\_Bridge Operation





|               |          |
|---------------|----------|
| <b>PEELLE</b> | CAR DOOR |
| CHANNEL       | 15       |
| PARAMETER     | 52       |
| SETTING       | 00       |

9. Set parameter 52 to “00” for Front Car Door or “01” for Rear Car Door.

|               |          |
|---------------|----------|
| <b>PEELLE</b> | CAR DOOR |
| CHANNEL       | 15       |
| PARAMETER     | 65       |
| SETTING       | 07       |

10. Set parameter 65 to “07” for Dual Light Curtain Test Output setting. see section 3.8 on page 18.



**Note see output USER 1**



CLOSE

11. Press and hold the CLOSE button to close the door.



12. Set AUTO<->IND switch to AUTO.



## 5.4 LANDING DOOR COMMISSIONING STEPS


- Ensure Landing Door interlock is mechanically unlocked. Ideally car is level at floor with retiring cam extended
- Ensure all EUD switches are set to the SET position




1. Turn power ON




2. Set AUTO<>IND switch to IND




3. Using the OPEN and CLOSE buttons, ensure the landing door operators are phased for correct rotation. If a motor rotates in the wrong direction, switch any two of the three motor wires.




4. To begin, cycle through parameters by pressing the - & + buttons. Once the desired parameter is displayed, press the ENTER button to access the setting for that parameter. Change the setting by pressing the - & + buttons. Once the desired setting is displayed, press the ENTER button to save the setting. Parameters can only be modified in IND mode.




5. Change parameter 02 to “Ld” setting. The LCD display should now read “landing door”.




6. Change parameter 03 to match the channel of the adjacent car door. All the landing doors for the front line must have the same channel as the front car door. The LCD display will show what channel has been selected.



7. Change parameter 04 to address the landing door. Use “ADDRESS 01” for the lowest door in a line of doors. Each additional landing door in line should be addressed in sequence (01, 02, 03 Etc). The LCD display will show what address has been selected.



8. Change parameter 10 to “Lr” setting. Press ENTER to begin learn cycle. Prior to learn, Landing Door can be in any position. The learn cycle will fully close and then fully open. Once the Landing Door is fully open, the learn cycle is complete and the flashing “LEARN” indicator on the LCD will turn off.



9. Press and hold the CLOSE button to close the door.




10. Set AUTO<>IND switch to AUTO.




## 5.5 OPERATION AND TESTING - FROM THE CAR DOOR CONTROLLER

With the CAN connection from the bridge controller removed, test the following Sequence of Operation using the OPEN, CLOSE and RETCAM buttons on the car door controller from the top of the car.



1. Remove the CAN connector to the controller
2. Make sure the controllers are set to AUTO
3. Use the OPEN, CLOSE and RETCAM buttons to test the door and car door and retiring cam sequence of operation.
4. Reconnect the CAN connector.

## 5.6 SEQUENCE OF OPERATION



For USER 1 and 2 options, see parameter 65 and 85



**THE PEELLE COMPANY**  
 FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
 TECHNICAL SUPPORT 1-800-787-5020 ext 275

## 5.7 LOSS OR POWER/BATTERY BACKUP/POWER UP MODE

### **ATTENTION!**

Landing door and Car door settings and speed profiles are retained by the controller when power is removed. It is not necessary to relearn the opening.

### **SHORT TERM POWER LOSS**

In the event of a short-term power loss (less than 15 minutes), both car door and landing door controllers are equipped with an onboard battery backup system that will monitor door position.

If power is restored within the 15 minutes, the operating profile (full speeds) will be restored as well as the DOOR OPEN or DOOR CLOSED outputs depending on car/landing door position.

### **LONG TERM POWER LOSS**

In the event of an extended power loss, battery backup power will be lost.

After power-up with the elevator car at a landing and upon automatic initiation of either open or close, the landing door and car door will operate at slow speed until the final open or final closed position is reached and held for one second.

At that point, the normal operating profile (full speeds) will be restored as well as the DOOR OPEN or DOOR CLOSED outputs depending on car/landing door position.

All unzoned landing doors will power up with the normal operating profile.



## 5.8 BRIDGE COMMISSIONING

Complete this commissioning after door operation testing, section 5.3




1. Turn power ON




2. Set AUTO<>IND switch to IND



3. Set FRONT<>REAR switch to desired setup. Both front and rear are commissioned independently.




4. To begin, cycle through parameters by pressing the - & + buttons. Once the desired parameter is displayed, press the ENTER button to access the setting for that parameter. Change the setting by pressing the - & + buttons. Once the desired setting is displayed, press the ENTER button to save the setting. Parameters can only be modified in IND mode.




5. Set parameter 15 to desired Auto Close time. Setting "00" Auto Close is disabled.

- Auto Close set times: 30, 45, 60, 90, 120, 150, 180, 300 seconds.



6. Set parameter 16 to elevator code jurisdiction.

- New York City RS18 = "01"
- All others = "00"




7. Set parameter 17 for single or dual light curtains.

- Single Light Curtain = "00"
- Dual Light Curtains (2010 code compliance) = "01"



**Also make sure to change your Car Door Controller Parameters 65 to "07" for dual light curtains.**




8. If required select USER1 or USER2 for desired relay output. See section Bridge Parameters, and elevator control prints.

- USER 1 = Parameter 18
- USER 2 = Parameter 19



9. Set AUTO<>IND switch to AUTO.



10. Using the OPEN, CLOSE and RETCAM cam buttons, ensure the doors are functioning from the Bridge Controller.




## 5.9 LANDING AND CAR DOOR INTERLOCKING CIRCUITS

### Wiring

Note: The following interlock safety circuit wiring is for reference only.

REFER TO THE ELEVATOR PRINTS FOR PROPER INTERLOCK WIRING.



### Elevator Control Operation

- 1) All DC (hoistway door closed) and GC (car gate closed) contacts should be connected in series and that the contacts be made when the doors and gates are closed.
- 2) All DI (hoistway door lock) contacts should be connected in series and the contacts be made when all doors are locked.

When the elevator controller is signaled, “all doors closed” through the DC and GC circuits, the elevator controller may initiate retiring cam operation (see Retiring Cam Initiation Contact). Initiation will cause the retiring cam face to retire (lift). When the interlock roller is no longer depressed by retiring cam, hoistway door locking action takes place and the elevator controller is signaled, “all doors locked” through the Di circuit. The elevator controller shall not allow the elevator car to run unless all DC (hoistway door closed) and GC (gate closed) and DI (hoistway door locking) contacts are made.

### Sequence of Operation

|  |                                |               |                  |                      |                  |
|--|--------------------------------|---------------|------------------|----------------------|------------------|
| INTERLOCK SAFETY CIRCUIT AND RETIRING CAM INITIATION | CAR DOOR (GATE) CLOSED CIRCUIT | GC (X1-X2/X7) | OPEN             | CAR DOOR CLOSED      | OPEN             |
|  | LANDING DOOR CLOSED CIRCUIT    | DC (X3-X4/X5) | OPEN             | LANDING DOORS CLOSED | OPEN             |
|  | RETIRING CAM INITIATION        | RC [INPUT 5]  | DROPPED          | RETIRING CAM LIFTS   | DROPPED          |
|  | LANDING DOOR LOCKED CIRCUIT    | DI (X5-X6/X9) | UNLOCKED         | LANDING DOORS LOCKED | UNLOCKED         |
|  | ELEVATOR CAR MOVEMENT          |               | ELEVATOR STOPPED | ELEVATOR CAR MOVING  | ELEVATOR STOPPED |



**THE PEELLE COMPANY**  
 FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
 TECHNICAL SUPPORT 1-800-787-5020 ext 275

34


**Guide No. 266-EN**

WIRELESS CONTROLLER & BRIDGE  
 INSTALLATION & INTERFACE GUIDE

Date: MAR / 2023

## 6.0 CONTROLLER SETTINGS

### 6.1 DOOR MOTION PROFILES



### 6.2 CAR & LANDING DOOR CONTROLLER PARAMETERS

| Parameter | Description  | Range    | Landing Pre Set | Car Pre Set |
|-----------|--|----------|-----------------|-------------|
| 1         | Reset Overload (00 = Do not reset, 01 = Reset)   | 00-01    | 00              | 00          |
| 2         | Controller Type: Car Door, Landing Door, Slave   | Cd,Ld,SL | Ld              | Ld          |
| 3         | Channel: set a unique Channel for each line of doors   | 11-26    | 26              | 26          |
| 4         | Floor: set a unique Floor address for each Landing Door<br>(note: 00 is not a valid address) | 01-98    | 00              | N/A         |
| 10        | Learn Command: used to learn the opening   | Lr or -- | --              | --          |
| 11        | Learn Speed: set learn and power-up speed  | 40-70    | 40              | 40          |
| 12        | Torque Boost   | 10-40    | 40              | 10          |
| 23        | Open High Speed: set the opening high speed  | 35-99    | 99              | 99          |
| 24        | Open Deceleration Zone: set distance of deceleration ramp                                    | 00-30    | 10              | 10          |
| 25        | Open Low Speed: set low speed open   | 20-99    | 50              | 30          |
| 26        | Open Low Speed Zone  | 00-30    | 10              | 10          |
| 27        | Open Hold Torque: set the hold open torque   | 00-50    | 25              | 20          |
| 28        | Fire Lintel Open Slowdown  | 10-90    | 50              | N/A         |
| 41        | Close High Speed: set the closing high speed   | 35-99    | 99              | 85          |
| 42        | Close High Speed Torque Limit  | 30-99    | 99              | 99          |
| 43        | Close Nudging Speed  | 30-70    | N/A             | 50          |
| 44        | Close Nudging Speed Torque Limit   | 30-99    | N/A             | 99          |
| 45        | Close Deceleration Zone: set distance of deceleration ramp                                   | 00-30    | 10              | 10          |
| 46        | Close Low Speed: set low speed close   | 20-99    | 50              | 30          |
| 47        | Close Low Speed Zone: set distance of low speed zone   | 00-20    | 10              | 10          |
| 48        | Close Hold Torque: set the hold close torque   | 00-50    | 25              | 20          |
| 49        | Fire Lintel Close Slowdown   | 10-90    | 50              | N/A         |



| Parameter                | Description  | Range    | Landing Pre Set  | Car Pre Set      |
|--------------------------|--|----------|------------------|------------------|
| 50                       | Control Interface: set discrete or CAN bus interface   | 00-02    | N/A              | 00               |
|                          | 00 = discrete, 01 = CAN (High Speed), 02 = CAN (Low Speed)                                       |          |                  |                  |
| 52                       | Car Door Designation: 00 = Front, 01 = Rear  | 00-01    | N/A              | 00               |
|                          | (only displayed if Parameter 50 = 01 or 02)  |          |                  |                  |
| 53                       | CmcMedia: 00 = RF, 01 = Wired RS_485   | 00-01    | 00               | 00               |
| 54                       | USING AS REPLACEMENT CONTROLLER<br>If Parameter 80 is 18 or lower change Parameter 54 to 01      | 00-01    | 00               | 00               |
| 55                       | Lost Communication Reaction Time   | 04-18    | 10               | 10               |
|                          | 04 = 0.4sec<br>05 = 0.5sec<br>...<br>18 = 1.8sec   |          |                  |                  |
| 60                       | Deceleration rate  | 01-10    | 03               | 03               |
| 61                       | Acceleration rate  | 01-10    | 03               | 03               |
| 62                       | USER 2 Close Limit: set position of the user door close limit                                    | 70-99    | 75               | 75               |
| 63                       | USER 1 Open Limit: set position of the user door open limit                                      | 70-99    | 75               | 75               |
| 64                       | User Limits Setting:   | 00-01    | N/A              | 00               |
|                          | 00 = landing door USER limit + car door USER limit sets USER relay output on car door controller |          |                  |                  |
|                          | 01 = car door USER limit sets USER relay output on car door controller                           |          |                  |                  |
| 65                       | USER 1 options   | 00-06    | 03               | 00               |
|                          | 00 = USER1POSITION   |          |                  |                  |
|                          | 01 = USER2POSITION   |          |                  |                  |
|                          | 02 = ZONE  |          |                  |                  |
|                          | 03 = BUZZ / STROBE   |          |                  |                  |
|                          | 04 = DOOR OPEN POSITION  |          |                  |                  |
|                          | 05 = DOOR CLOSED POSITION  |          |                  |                  |
|                          | 06 = AUX2 INPUT  |          |                  |                  |
|                          | 07 = LCT (BRIDGE MODE ONLY P50=01 or 02)   |          |                  |                  |
|                          | 08 = OVERLOAD  |          |                  |                  |
|                          | 09 = OVERDUTY  |          |                  |                  |
| 10 = OVERLOAD / OVERDUTY |  |          |                  |                  |
| 70                       | Retiring Cam Lift Type   | 00-02    | N/A              | 00               |
|                          | 00 – High Torque   |          |                  |                  |
|                          | 01 – Noise Reduction<br>02 – Full Speed  |          |                  |                  |
| 71                       | Retiring Cam Drop Type   | 00-01    | N/A              | 00               |
|                          | 00 – Unpowered<br>01 – Noise Reduction   |          |                  |                  |
| 72                       | Retiring Cam Duty Control  | 00-02    | N/A              | 01               |
|                          | 00 = Disabled (contact Peelle if used)   |          |                  |                  |
|                          | 01 = 50% Duty<br>02 = 75% Duty   |          |                  |                  |
| 80                       | Software Version (read only)   | 2 digits | Software Version | Software Version |
| 81                       | Radio Strength   | 01-31    | 31               | 31               |
| 82                       | Motor DutyControl  | 00-02    | 01               | 01               |
|                          | 00 = Disabled (contact Peelle if used)   |          |                  |                  |
|                          | 01 = Standby Duty<br>02 = Increased Duty   |          |                  |                  |
| 83                       | Motor Overload Control   | 00-02    | 01               | 01               |
|                          | 00 = Disabled (contact Peelle if used)   |          |                  |                  |
|                          | 01 = Default Threshold<br>02 = Increased Threshold   |          |                  |                  |
| 84                       | Drive Over Temperature Control   | 00-02    | 01               | 01               |
|                          | 00 = Disabled (contact Peelle if used)   |          |                  |                  |
|                          | 01 = Default Threshold<br>02 = Increased Threshold   |          |                  |                  |





|    |   |          |               |               |
|----|---|----------|---------------|---------------|
| 85 | USER 2 options<br>00 = USER 2 POSITION<br>01 = USER 1 POSITION<br>02 = ZONE<br>03 = BUZZ / STROBE<br>04 = DOOR OPEN POSITION<br>05 = DOOR CLOSED POSITION<br>06 = AUX2 INPUT<br>07 = LCT (BRIDGE MODE ONLY P50=1)<br>08 = OVERLOAD<br>09 = OVERDUTY<br>10 = OVERLOAD / OVERDUTY | 00-06    | 03            | 00            |
| 86 | Retiring Cam Lift Torque Boost  | 00-24    | NA            | 0             |
| 87 | SIMULTANEOUS OPERATION (INPUT 4 HIGH)<br>00= CLOSE DIRECTION ONLY<br>01 = OPEN AND CLOSE DIRECTION  |          |               |               |
| 88 | Car Door Aux2 Input Option<br>00=Disabled<br>01 = Independent Car Door Operation with input ON  | 00-01    | N/A           | 00            |
| 89 | Momentary Door Open / Door Close Option<br>00=Constant DO and DC operation<br>01 = Momentary DO and DC operation  | 00-01    | N/A           | 00            |
| 93 | Power Up landing door speed (unzoned only)<br>00=learn speed until final open/close limit<br>01=normal profile speed  | 00-01    | 01            | N/A           |
| 94 | Buzzer Output: 00 = Pulsing, 01 = Continuous  | 00-01    | 01            | 00            |
| 95 | Close Input Buzzer Control: 00 = Disabled, 01 = Enabled   | 00-01    | 01            | 01            |
| 96 | Hall Stop Button Input:<br>00 = Normally Open, 01 = Normally Closed   | 00-01    | 00            | N/A           |
| 97 | Power-Up Settings:  | 01-03    | 02            | 02            |
|    | 01 – Door Closed = 1, Door Open = 1;  |          |               |               |
|    | 02 – Door Closed = 1, Door Open = 0;  |          |               |               |
|    | 03 – Door Closed = 0, Door Open = 0;  |          |               |               |
|    | If zoned, both Door Closed and Door Open = 0, regardless of selection.<br>Condition of outputs is established automatically after opening or closing cycle  |          |               |               |
| 98 | Show Cycle Counter  | 6 digits | Cycle Counter | Cycle Counter |
| 99 | Restore Factory Default Settings  | 00-02    | 00            | 00            |
|    | 00 – Exit without saving  |          |               |               |
|    | 01 – Restore all Motor parameters (#20 – 97)  |          |               |               |
|    | 02 – Restore all parameters (#2 – 97)   |          |               |               |

N/A – Not available

Speeds are expressed as a percentage of full speed. Zone is expressed as a percentage of total travel. Torque is expressed as a percentage of nominal voltage for corresponding speed.



## 6.3 BRIDGE CONTROLLER PARAMETERS



Bridge Controllers will show a “br” on the LCD display

| Parameter | Description  | Range                                  | Default     |
|-----------|--|--|-------------|
| 11        | CAN Speed<br>00 – High Speed<br>01 – Low Speed (use for long cable runs)   | 00-01                                  | 00          |
| 12        | 15 Seconds Screen View   | 00-01                                  | 00          |
| 13        | Momentary Close  | 00-01                                  | 00          |
| 14        | Power Up Auto Close  | 00-02                                  | 01          |
| 15        | Auto Close Timing  | 00, 30, 45, 60, 90, 120, 150, 180, 300 | 00          |
| 16        | New York City  | 00-01                                  | 00          |
| 17        | light curtain Test   | 00-01                                  | 00          |
| 18        | User 1 Selectable<br>00 = USER_1_FRONT<br>01 = USER_2_FRONT<br>02 = ZONE_FRONT<br>03 = BUZZ_STROBE_FRONT<br>04 = DOOR_OPEN_FRONT<br>05 = DOOR_CLOSED_FRONT<br>06 = AUX_2_FRONT<br>07 = USER_1_REAR<br>08 = USER_2_REAR<br>09 = ZONE_REAR<br>10 = BUZZ_STROBE_REAR<br>11 = DOOR_OPEN_REAR<br>12 = DOOR_CLOSED_REAR<br>13 = IS_AUX_2_REAR<br>14 = OVERLOAD_FRONT<br>15 = OVERDUTY_FRONT<br>16 = OVERLOAD_OR_OVERDUTY_FRONT<br>17 = OVERLOAD_REAR<br>18 = OVERDUTY_REAR<br>19 = OVERLOAD_OR_OVERDUTY_REAR | 00-19                                  | 00          |
| 19        | User 2 Selectable<br>00 = USER_2_FRONT<br>01 = USER_1_FRONT<br>02 = ZONE_FRONT<br>03 = BUZZ_STROBE_FRONT<br>04 = DOOR_OPEN_FRONT<br>05 = DOOR_CLOSED_FRONT<br>06 = AUX_2_FRONT<br>07 = USER_1_REAR<br>08 = USER_2_REAR<br>09 = ZONE_REAR<br>10 = BUZZ_STROBE_REAR<br>11 = DOOR_OPEN_REAR<br>12 = DOOR_CLOSED_REAR<br>13 = IS_AUX_2_REAR<br>14 = OVERLOAD_FRONT<br>15 = OVERDUTY_FRONT<br>16 = OVERLOAD_OR_OVERDUTY_FRONT<br>17 = OVERLOAD_REAR<br>18 = OVERDUTY_REAR<br>19 = OVERLOAD_OR_OVERDUTY_REAR | 00-19                                  | 00          |
| 20        | Bridge Software Version(Read Only)   | 2 digits                               | 05(current) |
| 21        | Reset to default setting   | 00-01                                  | 00          |



## 7.0 TROUBLESHOOTING

### 7.1 INDEPENDENT MODE

PEELLE ONLY OPERATION - USED FOR COMMISSIONING AND INDIVIDUAL LANDING/CAR DOOR OPERATION  
(AUTO-IND slider switch set to IND)

| Problem                                    | Possible Cause   | Action  |
|--|--|---|
| No operation from OPEN/CLOSE pushbutton    | AUTO-IND slider not set to IND   | Set AUTO-IND slider to IND  |
|  | Wiring problem to Landing Door motor output or Car Door selector relay output  | See page 6 for Landing Door motor wiring  |
|  |  | See pages 15 & 16 for Car Door/Retiring Cam motor wiring  |
|  | Flashing LCD “OVERLOAD” icon   | Duty timer for motor has been exceeded. Cool down period required for motor regeneration. If condition persists, increase duty timer. See parameters P72 & P82.<br>Note: increasing duty timer may shorten motor life |
| Constant LCD “OVERLOAD” icon               | Check Landing Door motor output or Car Door selector relay output for short circuit to ground<br>See page 6 for Landing Door motor wiring<br>See pages 15 & 16 for Car Door/Retiring Cam motor wiring<br>Acknowledge “OVERLOAD” by setting parameter P01 to 01 |   |
| No operation from RETCAM pushbutton        | Controller type not set to Car Door (CD)   | Ensure parameter P02 is set to “CD”   |
|  | Wiring problem to Car Door selector relay output   | See pages 15 & 16 for Car Door/Retiring Cam motor wiring  |
| Slow speed Landing/Car Door operation only | LCD “LEARN” flashing   | Operational profile not learned. Set parameter P10 to “Lr” to initiate learn sequence   |
| Landing/Car door runs for 12” then stops   | Encoder set screw loose  | Ensure set screw is tight on encoder shaft  |
|  | Encoder wiring problem   | See page 5 for Landing Door encoder wiring<br>See pages 14 for Car Door encoder wiring<br>Move door manually and check that encoder count on LCD is changing  |
| Retiring Cam not fully pulling back        | Mechanical problem with bottom assembly (face)   | Ensure bottom assembly moves freely on pivot pins<br>Ensure connecting rod is parallel to bottom assembly (face) and top assembly (motor)   |
|  | Mechanical problem with top assembly (motor)   | Ensure pulley belt has 3/4” of deflection   |
|  | Mechanical problem with full assembly  | Ensure when pulling back that pickup arm on top assembly starts at 6 o’clock and rotates towards middle of car to either 9 o’clock or 3 o’clock (depending on rotational direction)                                   |



## 7.2 AUTOMATIC MODE

PEELLE ONLY OPERATION - USED FOR COMBINED LANDING AND CAR DOOR OPERATION  
(AUTO-IND slider switch set to AUTO)

| Problem                                 | Possible Cause  | Action   |
|---|---|--|
| No operation from OPEN/CLOSE pushbutton | AUTO-IND slider not set to AUTO   | Set AUTO-IND slider to AUTO<br>All controllers must be set to AUTO.  |
|   | Elevator not in Landing Door zone   | Ensure retiring cam bottom assembly is on Landing Door roller arm  |
|   | LCD “ZONE” icon not on at either Landing Door controller or corresponding Car Door controller                 | Ensure Input 3 is on at Landing Door controller.   |
|   | LCD “ANTENNA” icon not on (or flashing) at zoned Landing Door controller or corresponding Car Door controller | Ensure Landing Door channel matches Car Door channel. Adjust parameter P03 if necessary<br>Ensure Landing Door address is unique and not set to 00. Adjust parameter P04 if necessary  |
|   | LCD “EUD” icon on (or flashing) at Landing Door controller and flashing at corresponding Car Door controller  | Constant LCD “EUD” icon = EUD is in STOP position at current landing<br>Flashing LCD “EUD” icon = EUD is in STOP position at another landing on the same channel<br>See page 9.  |
|   | LCD “MULTIZONE” icon on at Landing Door controller and corresponding Car Door controller                      | Check all interlock zone micro switches. Only one zone micro switch can be on at a time on one channel.  |
|   | Flashing LCD “OVERLOAD” icon  | Duty timer for motor has been exceeded. Cool down period required for motor regeneration. If condition persists, increase duty timer. See parameters P72 & P82.<br>Note: increasing duty timer may shorten motor life  |
|   | Constant LCD “OVERLOAD” icon  | Check Landing Door motor output or Car Door selector relay output for short circuit to ground<br>See page 6 for Landing Door motor wiring<br>See pages 15 & 16 for Car Door/Retiring Cam motor wiring<br>Acknowledge “OVERLOAD” by setting parameter P01 to 01 |



## 7.3 ELEVATOR INTERFACE OPERATION

| Problem  | Possible Cause   | Action  |
|--|--|---|
| Elevator controller is sending outputs to Bridge controller but no Landing / Car Door operation in open or close direction | Are LCD input icons on Bridge controller?<br>If not check the following:<br><br>If Peelle power is used to power Peelle inputs, missing jumper from Input Com terminal to V- terminal on Car Door controller<br><br>If external power is used to power Peelle inputs, missing external power reference wire on Input Com terminal on Car Door controller   | LD & CD on Auto?<br><br>Add jumper from Input Com to V-. See page 22<br><br>Ensure external power reference is wired to Input Com. See page 22<br><br>Ensure external power reference is wired to Input Com. See page 22<br><br>Note: ensure no connections to Peelle V+/V-<br><br>Ensure parameter P50 is set to 00 on Car Door Controller |
|  | Is antenna icon solid on Bridge controller?<br>If not...   | Check CAN connection from Bridge Controller to Car Door Controller  |
| Bridge controller is sending signal to car door controller but no Landing/Car Door operation in open or close direction    | Are LCD input icons on Car Door controller?<br>If not check the following:<br><br>If Peelle power is used to power Peelle inputs, missing jumper from Input Com terminal to V- terminal on Car Door controller<br><br>If external power is used to power Peelle inputs, missing external power reference wire on Input Com terminal on Car Door controller | Add jumper from Input Com to V-. See page 22<br><br>Ensure external power reference is wired to Input Com. See page 22<br><br>Note: ensure no connections to Peelle V+/V-<br><br>Ensure parameter P50 is set to 00.   |
|  | Landing Door stop input on   | Ensure input 5 is off on Landing Door controller.<br>See page 10<br><br>See Automatic Mode chart  |
|  | Landing/Car door stopped before final open/close   | Door may be mechanically obstructed. Fix obstruction.<br>If there is not enough power in slow speed for final open or final close, increase the following parameter(s) in multiples of 5 until fixed:<br>Open direction - P27<br>Close direction - P48  |
| Bridge controller is sending signals to car door controller but no Landing/Car Door operation in close direction           | Light curtain obstructed   | Check light curtain alignment<br><br>For dual light curtains ensure P65 is set to 047 on car door controller  |
| Antena flashing on bridge controller   | Wiring problem on car door controller  | Verify that V+ Front and V+ Rear car doors are wired independently.<br>Do not connect them together.  |



## 7.4 ERROR CODES

If the setting is flashing from encoder count (5 digits) to and error code (4 digits) refer to the following.

### How to read


Example: Car Door Error 06 10

The first two digits are the sum of the first four possible errors.


$$06 = 02 \text{ (car door motor run error)} + 04 \text{ (car motor over duty)}$$

The last two digits are the sum of the last four possible errors.

$$10 = 02 \text{ (EUD error)} + 08 \text{ (lost zone)}$$



To clear error codes cycle the AUTO-IND slider switch



## 7.5 LANDING DOOR LCD

### Radio Communication

- Antenna is ON solid when elevator is at a floor and door is ZONED
- Antenna is ON solid when EUD is SET whether door is ZONED or not
- Antenna is OFF when elevator is not ZONED
- For intermittent flashing in ZONE adjust channel selection

### Multiple Zone

- MULTIZONE indicator is shown when two or more landing door controllers are ZONED on the same channel
- Check zone switches and ZNS inputs at landings

### Number Display

- Number display show encoder count (door position)
- Approximately 0-50 for landing door closed position
- Full count for open position
- May flash fault codes for Peelle Use

### Input Indicators

- 1 HDO - Hall door open button
- 2 HDC - Hall door closed button
- 3 ZNS - Floor Zone switch
- 4 EUD - Emergency Unlocking Device
- 5 STOP - hall door stop button
- 6 AUX1 - Not Used
- 7 AUX2 - Not Used
- 8 RE - Hall door light curtain input (where provided)

### Motor Overload / Over Duty


- OVERLOAD is ON solid when over current exists at motor output
  - Check for shorts on motor line
  - Check for shorts to ground
- Reset of overload is required; set parameter 01 to 01 and press ENTER to clear (must go to IND mode)
- OVERLOAD is flashing when motor run time exceeds duty
  - Let motor reset for 5 minutes
- Over Duty does not require reset

### Landing Zone

- Zone is ON solid when elevator is at a floor with retiring cam extended and door unlocked
- Input indicator 3 ZNS is ON when door is ZONED
- Zone and 3 are OFF when doors are locked and / or car is moving between floors
- Doors will not run if ZONE is not made
- Check ZNS and zone switch

### Door Stop Sign

- Door Stop Sign is ON whenever motors are not running
- Door Stop Sign is OFF when power is being applied to motors



### Emergency Unlocking Device

- EUD is ON solid when EUD is STOP at that floor
- Input indicator 4 is ON when EUD is STOP at that floor
- EUD is flashing when EUD is STOP at another floor on same channel
- Doors will not run if any EUD is STOP on the same channel



## 7.6 CAR DOOR LCD

### Radio Communication

- Antenna is ON solid when elevator is at a floor and door is ZONED
- Antenna is OFF when elevator is travelling
- Antenna is Flashing Constant when elevator is not ZONED
- For intermittent flashing in ZONE adjust channel selection

### Multiple Zone

- MULTIZONE error is shown when two or more landing door controllers are ZONED on the same channel
- ZONED floor addresses are shown in Number Display
- Check ZONE switches and ZNS inputs at landings

### Number Display

- Number display show encoder count (car door position)
- Approximately 0-50 for car door closed position
- Full count for open position
- Will show floor addresses in MULTIZONE error
- Shows floor addresses when and EUD is SET
- May flash fault codes for Peelle Use

### Input Indicators

- 1 DO - Door open command from elevator
- 2 DC - Door closed command from elevator
- 3 SE - Close nudging command from elevator
- 4 DCM - Fast close command from elevator
- 5 RC - Retiring cam command from elevator
- 6 BUZZ - Close warning buzzer command from elevator
- 7 AUX2 - Not Used
- 8 RE - Reversing edge input from car door

### Motor Overload / Over Duty


- OVERLOAD is ON solid when over current exists at motor output
- Check for shorts on motor line
- Check for shorts to ground
- Reset of overload is required; set parameter 01 to 01 and press ENTER to clear (must go to IND mode)
- OVERLOAD is flashing when motor run time exceeds duty
- Let motor reset for 5 minutes
- Over Duty does not require reset

### Landing Zone

- Zone is ON solid when elevator is at a floor with retiring cam extended and door unlocked
- Zone is OFF when all doors are locked and / or car is moving between floors
- Doors will not run if ZONE is not made
- Check ZNS and zone switch

### Door Stop Sign

- Door Stop Sign is ON whenever motor is not running
- Door Stop Sign is OFF when power is being applied to motor



### Emergency Unlocking Device

- EUD is flashing when an EUD has been STOP
- EUD is OFF when all landing doors have been RUN
- Floor addresses where EUD is STOP are shown in the Number Display
- Doors will not run if any EUD is STOP on the same channel






## 7.7 BRIDGE LCD

### FRONT or REAR Selector

- LCD shows indicators according to selector switch
- Parameters setting according to selector switch



### CAN Communication

- Antenna is ON solid when Bridge is communicating with Car Door controller
- Antenna is Flashing constant when CAN is not communicating

### Multiple Zone

- MULTIZONE error is shown when two or more landing door controllers are ZONED on the same channel
- ZONED floor addresses are shown in Number Display
- Check ZONE switches and ZNS inputs at landings

### Motor Overload / Over Duty


- OVERLOAD is ON solid when over current exists at motor output
- Check for shorts on motor line
- Check for shorts to ground
- Reset of overload is required; set parameter 01 to 01 and press ENTER to clear (must go to IND mode)
- OVERLOAD is flashing when motor run time exceeds duty
- Let motor reset for 5 minutes
- Over Duty does not require reset

### Landing Zone

- Zone is ON solid when elevator is at a floor with retiring cam extended and door unlocked
- Zone is OFF when all doors are locked and / or car is moving between floors
- Doors will not run if ZONE is not made
- Check ZNS and zone switch

### Input Indicators

- 1 DOR - Rear Door Open
- 2 DCR - Rear Door Close
- 3 INSR - Rear Inspection
- 4 DCMR - Rear Door Close Momentary
- 5 X13 - Phase 2 "ON"
- 6 X14 - Phase 2 "HOLD"
- 7 X18 - Phase 2 "OFF"
- 8 HDB - Hall Door Buttons



### Input Indicators

- 1 DO - Front Car Open
- 2 DC - Front Door Close
- 3 INS - Front Inspection
- 4 DCM - Front Door Close Momentary
- 5 RC - Retring Cam
- 6 X11 - Fire Service Phase 1 "RECALL"
- 7 X12 - Designated Landing / Auto Close Disable
- 8 RE - Not Used

### Emergency Unlocking Device

- EUD is flashing when an EUD has been STOP
- EUD is OFF when all landing doors have been RUN
- Floor addresses where EUD is STOP are shown in the Number Display
- Doors will not run if any EUD is STOP on the same channel

### Door Stop Sign

- Door Stop Sign is ON whenever motor is not running
- Door Stop Sign is OFF when power is being applied to motor



**THE PEELLE COMPANY**

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
**TECHNICAL SUPPORT** 1-800-787-5020 ext 275

45

**Guide No. 266-EN**

WIRELESS CONTROLLER & BRIDGE  
 INSTALLATION & INTERFACE GUIDE

Date: MAR / 2023

## 8.0 TECHNICAL SPECIFICATIONS

### 27450 WIRELESS BRIDGE CONTROLLER

#### Technical Data



|                          |  |
|--------------------------|--|
| Input Power              | 208 - 240Vac - 5A - 6A, 50/60Hz                        |
| Supply Voltage           | 208-240V, 1 Ø AC, 50/60Hz                              |
| Output Power             | 0-240Vac 4.2A Max 3Phase                               |
| Output Motor             | 0.75 kW (1 HP)   |
| Digital Inputs           | 8 provided, 12-30V, AC or DC                           |
| Encoder Input            | Incremental, NPN, 12VDC, 120 PPR                       |
| Relay Outputs            | 8 provided, Form C, 10A, 125VAC                        |
| Input Indicators         | LCD screen   |
| Output Indicators        | LED  |
| Enclosure Protection     | NEMA 1,4,4X (indoor use only) - IP 65                  |
| Temperature              | 40 Deg C Max   |
| Dimensions               | 200mm x 430mm x 85mm (W x H x D)                       |
| Mounting Method          | 4 screw holes on outside perimeter                     |
| Equipment Class          | Digital Transmission System                            |
| Wireless Network         | 802.15.4 LR-WPAN standard                              |
| Wireless Frequency       | 2.4GHz   |
| Wireless Output          | 0.094 Watts  |
| Wireless Range           | 100m floor-to-floor up to 99 floors                    |
| User Interface           | On board pushbuttons with visual display               |
| Visual Display           | 50mm x 40mm back-lit LCD                               |
| Parameters               | User adjustable with factory presets and defaults      |
| Learn Adjustment         | Automatic by user parameter                            |
| Landing Door Address     | User selectable parameter                              |
| Car or Landing Door Type | User selectable parameter                              |
| Fail Safe Condition      | Door Stop if communication lost                        |
| Battery Specifications   | Type: NiMH Size: AAA Capacity: 700mAh<br>Voltage: 1.2V |

#### Standards

Elevators and Lifts  
 ASME-A17.1/CSA-B44  
 ASME-A17.5/CSA-B44.1  
 EN 81  
 EN 12015 and EN12016  
 Telecommunication  
 FCC  
 Industry Canada  
 R&TTE Directive

#### Certification

ETL Listing and Certification Mark  
 FCC Grant of Equipment Authorization  
 Industry Canada Certificate of Acceptance



**THE PEELLE COMPANY**  
 FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
 TECHNICAL SUPPORT 1-800-787-5020 ext 275

## 9.0 EC DECLARATION OF CONFORMITY

### FCC STATEMENT

**Wireless Radio FCC ID: 2AYO9-WFDCRFIF**

**Equipment Class: Digital Transmission System**

**Notes: 802.15.4 Transceiver Module**

This device complies with part 15 of FCC rules. Operation is subject to the following two conditions: (1) the device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by The Peelle Company could void the user's authority to operate the equipment under FCC.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The user should avoid prolonged exposure within 20cm of the antenna, which may exceed the FCC radio frequency exposure limits.

### ISED STATEMENT

**Model: 2745**

**IC: IC 26868-WFDCRFIF**

This device complies with Innovation, Science and Economic Development Canada's license-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. The user should avoid prolonged exposure within 20cm of the antenna, which may exceed the ISED radio frequency exposure limits.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet équipement est conforme aux limites d'exposition aux rayonnements définies par l'ISDE pour un environnement non contrôlé. L'utilisateur doit éviter une exposition prolongée à moins de 20 cm de l'antenne, qui pourrait excéder les limites d'exposition aux fréquences radio ISED



## 10.0 EC DECLARATION OF CONFORMITY

Manufacturer:

The Peelle Company Ltd.  
195 Sandalwood Pkwy W.  
Brampton, Ontario L7A 1J6  
CANADA

We, The Peelle Company Limited of Brampton, Ontario, declare that the product designated below complies with the relevant fundamental requirements of Article 3 of the Lifts directive 2014/33/EU insofar as the product is used as intended and the following standards applied:

Product: Wireless Freight Door Controller, 2.4GHz, 802.15.4 Transceiver Module

Manufactured by: The Peelle Company Ltd. Trade mark: Peelle

Model: WFDC 27451 Car Door, WFDC 27452 Landing Door

Environment of use: Residential, commercial and light industry

Standards:

-Lifts EN 81-20:2014 Safety rules for the construction and installation of lifts

EN 12015:2014 Electromagnetic compatibility – Emissions

EN 12016:2013 Electromagnetic compatibility – Immunity

EN 61000-6-1:2007 Electromagnetic compatibility (EMC)

-Telecommunication EN 50371, EN 301 489-1, EN 301 489-17, EN 300 440

Date of issue: MAY 2017

Place of issue: Brampton, Ontario, CA

Frank Leo P.Eng.  
Engineering Manager



**THE PEELLE COMPANY**  
FREIGHT DOORS | CAR GATES | CAR ENCLOSURES  
**TECHNICAL SUPPORT** 1-800-787-5020 ext 275

48

**Guide No. 266-EN**

WIRELESS CONTROLLER & BRIDGE  
INSTALLATION & INTERFACE GUIDE

Date: MAR / 2023



